## PHONE SETUP

**VERIZON ONETALK T67LTE 4G DESK PHONE** 

## **INSTRUCTIONS:**

NOTE: Do not connect any other cables. This device will not connect to the existing network or existing phone cabling.

 Unbox phone. The box should include a phone, phone stand, power cord, and handset.



Attach phone stand. To attach
the optional phone stand, slide
the stand in from left to right
into the larger rectangular holes
until it securely snaps in place.



3. Plug in handset to the port with the handset icon.





4. Plug in power cord to the port labeled DC12V.





5. The phone is ready to be connected to power.



