



QUICK START GUIDE

YEALINK T73W

O P T U S +  Enterprise Mobility™ | 

SOLUTION LINE

833.487.0003

Option 6

DIALING PROCEDURES

Internal Extensions:

- Dial three digit extension.

External Number:


- Dial 10 digit number.

CALL PARKING

With the Call Parking feature, you can put an active call on hold and resume the call from any other phone in your organization. The site can have a maximum of four callers on park at any given time.

Parking a Call:

- Use buttons 5-8 to place a call on park and retrieve it.



BUTTON #	NAME
1	Line 1
2	Line 2
3	Line 3
4	Line 4
5	Park Pickup 1
6	Park Pickup 2
7	Park Pickup 3
8	Park Pickup 4



For the full User Guide,
scan the QR code.

T73W PHONE FEATURES

PLACING OUTGOING CALLS

When the phone is not in use:

1. Pick up the handset or press the "Speaker" button. 
2. Dial tone will be heard.

When you are already on a call:

1. Press the "Hold" soft key.
2. Press the "New Call" soft key.
3. Dial an extension or telephone number.
4. Resume the original call by pressing the "Resume" soft key.

ANSWERING AN INCOMING CALL

On the handset:

- Pick up the handset to answer the call.

On speakerphone:

- Press the "Speaker" button  to answer the call.

ENDING A CALL

On a handset:

- Hang up the handset or press the  soft key followed by the "End Call" soft key.

On speakerphone:

- Press the "Speaker" button. 

HOLD

Placing a call on hold:

- While on a call, press the "Hold" soft key.

Retrieving calls on hold:

- Press the "Resume" soft key.

TRANSFERRING CALLS

1. While on a call, press the "Transfer" soft key.
2. Dial the desired phone number or extension number.
3. Press the "Transfer" soft key again.
4. The call is automatically transferred.

VOLUME ADJUSTMENT

In-Call Volume:

- While on a call, press the "+" and "-" buttons  to raise or lower the volume.

